VAPE KIT 3.0 USER MANUAL

IMPORTANT SAFETY NOTICE AND DISCLAIMER:

The **mCig®** is for adult consumption only, except in states where youth can deploy this device under the strict supervision of an adult via a doctors recommendation. The **mCig®** should be viewed as a recreational device in states or localities where adult use is permitted. In medical states or localities, the use of this device should be discussed with the medical professional that writes the recommendation for the individual's safety and intended efficacy. It should not be considered a safe alternative to cigarettes, tobacco, or other nicotine based products. The **mCig®** is not intended for curing or mitigating any disease or condition. The **mCig®** should not be employed to administer any illegal products in accordance with state and local law. Use of the device for illegal purposes voids the warranty. Do not use the **mCig®** device in public unless expressly permitted by the locality or state. Do not use the **mCig®** while operating a motor vehicle, motor craft, or heavy machinery. Do not operate the **mCig®** under the influence of alcohol.

TABLE OF CONTENTS

6 INTRODUCTION
7 GENERAL FUNCTION
8 PACKAGE CONTENTS
9 OVERVIEW
11 ACCESSORIES OVERVIEW
14 PREPARING / QUICK START

16 ACTIVATING
18 CHARGING
19 CLEANING
20 TIPS
21 WARNING
22 WARRANTY
24 LIMITED WARRANTY TERMS AND CONDITIONS

INTRODUCTION:

Welcome to the **mCig®** Vape Kit 3.0 technology. The **mCig®** 3 heats materials to the point of sublimation more commonly called vaporization without burning using both conduction and convection heat. Load the **mCig®** 3 with .2g to .25g of ground dry material, replace the mouth-piece, and rapidly press the button 3 times. Within 50 seconds the flashing blue light will turn solid. There is no need to wait until the light is solid, for some materials, the best taste can be found along the way. Gently breath in, exhale, welcome to the **mCig®**.

GENERAL FUNCTION:

Congratulations on your purchase of the **mCig®** Vape Kit 3.0. This device is precision crafted using advanced heating technology with industry leading expertise. The **mCig**® 3 vaporization technology is intended to reduce the harms associated with burning plant materials. It is easy and discreet to use in an array of environments from home to the outdoors.

PACKAGE CONTENTS

1 **mCig**
1 wax & e-liquid headting cup
1 18650 battery
1 cleaning brush
1 packing tool
1 tweezer
1 18650 charger
1 gift box
1 user manual

OVERVIEW

1. Mouthpiece
2. Connector Ring
3. Mesh Filter
4. Wax & e-liquid heating cup
5. Heating Chamber
6. Connector
7. Power Button
8. Battery Tube
9. 18650 Battery
10. Bottom Cap.

OVERVIEW



ACCESSORIES OVERVIEW

1. Charger
2. Tweezer
3. Cleaning Brush Tool
4. Packing Tool
5. Wax & e-liquid heating cup

ACCESSORIES OVERVIEW

ACCESSORIES OVERVIEW



wax & e-liquid heating cup

PREPARING / QUICK START:

It is recommended to fully charge the battery in the **mCig®** Vape Kit 3.0 until it is fully charged on first use. Be sure to match the polarity of the battery when putting it into the charger. The high capacity 2200mAh battery has a positive and negative symbol on opposite sides of the text written on the battery. Match this with polarity indicated inside of the battery charger.

Light indications on charger:

Solid Red = Charging
Solid Green = Fully Charged



ACTIVATING:

Once battery is charged, unscrew the cap (negative terminal) and insert positive end of battery into the **mCig®**. Screw the end cap back on the device. Remove mouthpiece by pulling straight away from the chamber. Grind up .2g to .25g and use the packing tool to insert material evenly inside of chamber. Keep the top of the chamber clear of dry material to allow a proper seal time and time again with the mouthpiece. Replace Mouthpiece. Tap button 3 times to turn on the device, gently inhale when light turns solid blue or feel free to try some great flavor after just 20-30 seconds of flashing.

Change the temperature from the Blue setting (374˚F) to Green setting by holding the power button in for 3 seconds, light will change color and flash until Green setting (410˚F) temperature is reached. To increase to the hottest setting indicated by Red (446˚F), hold the power button for 3 seconds, light will change color and flash until Red until maximum temperature is reached. To power off the device at any point, simply hit the button 3 times rapidly, as was done to turn it on initially.

The **mCig®** heating cup can be used with oils and waxes. It is magnetic and we recommend using the tweezers to remove it if used. A little bit of this material will go a long way.

Device has a safety feature that it automatically shuts off after 180 seconds.

374F
410F
446F

CHARGING:

New batteries should be fully charged before the first use. LED indicator will indicate charging on red, then transition to orange when half way charged. Once fully charged the indicator LED will be a solid green.

If at any point the power button blinks 8 times and shuts off, recharge the battery.

CLEANING:

After repeated use, the airflow may not be as strong when drawing on the **mCig®** or vapor amount is decreased. The mouthpiece needs to be cleaned. Use an alcohol soaked cotton swab or alcohol swab to clean off any resin that builds up on the mouthpiece. The same thing can be used on any material that collects where the mouthpiece seats in the chamber. If large amounts of dry material have caked here, try using the brush first, then alcohol soaked cotton.

The brush can be used to gently clean the walls of the chamber. Alcohol is only recommended to clean extreme resin buildup inside the chamber. Allow alcohol to dry thoroughly before using mouthpiece or chamber. Soak the heating cup in alcohol and allow to dry before redeploying.

TIPS:

Do not overfill the heating chamber or pack it too tight. Airflow is essential to deliver vapor.

Use a grinder for best vapor consistency with dry herb, .2g to .25g is optimal amount.

The **mCig®** 3 works with H2O & dry sieve resins as well as oil or wax soaked herb. If using concentrates, it is recommended to use pure dry herb at the base of the chamber to prevent clogging. Add concentrated resin towards the top of the chamber. Top the chamber with dry herb so the mouthpiece doesn't clog as well.

It is best to clean the **mCig®** 3 after it has cooled to the touch (about 60 seconds).

Do not grind seeds or stems and use with **mCig®** 3.

WARNING:

Do not reverse the polarity of the battery during installation.

WARNING CONTINUED:

Do not grind up stems or seeds and use with the device.

Do not use too much wax/oil/e-juice with heating cup. Keep any material added at a level below the filter. Keep device vertical to avoid anything spilling out of heating cup.

Wait at least 60 seconds before touching the inside of the chamber or the filter of the mouth-piece after using the **mCig®** 3.

Do not put the **mCig®** device in water or any liquids. Alcohol soaked cotton should be used sparingly and only when needed inside of the chamber. Don't dump alcohol liquid into cham-ber.

Do not insert foreign objects into any parts of the device. Only use included accessories for cleaning along with cotton or cloth, and alcohol sparingly.

WARRANTY:

1 Year Limited Warranty

mCig, Inc. warrants this **mCig®** 3 device against defects in materials and workmanship under normal use for a period of one year from the date of retail purchase by the original end-user purchaser. If a physical defect arises and a claim is received within the Warranty Period, at its option to the extent permitted by law, **mCig®**, Inc. will either:

1 Repair the product defected.
2 Exchange the product with a product that is new or another functionally equivalent product.
3 The Limited Warranty does not apply to normal performance degradation of batteries or neglecting to adhere to proper cleaning instructions.

LIMITED WARRANTY TERMS AND CONDITIONS:

mCig® chargers should never be left unattended on or near a carpet or rug area. Failure to follow this direction may in a burn to the carpet and may be a fire hazard.

In order to prevent overheating, only charge **mCig®** products for a maximum of 3 hours or until green light indicates the unit is fully charged. Do not leave the charger plugged in overnight. Do not plug the charger into a power strip.

LIMITED WARRANTY TERMS AND CONDITIONS:

mCig® will not be responsible for any special, consequential or incidental damages (including but not limited to the replacement of a carpet, rug, personal or other property)

mCig, Inc. is not responsible for any damage caused by inappropriate, incorrect, or irresponsible use of our products. The user agrees to accept responsibility for all such risks and not hold mCig, Inc., its distributors, or retailers (including owners and employees) responsible for any incident, injury to persons, or damage to property.

Warning:

Incompatible chargers may carry a different voltage, which maybe a fire hazard. For this reason, please use **mCig®** brand chargers. The use of a charger unit with different voltage will void the limited warranty offered on **mCig®** brand products.

LIMITED WARRANTY TERMS AND CONDITIONS CONTINUED:

Use only as directed!

Vaporizers are not medical devices and are not intended to cure, treat, or prevent any diseases or other conditions. If you have any health problems, please consult your doctor or state licensed medical professional before using any **mCig®** products. **mCig®** 3 Vaporizers are not intended to be used with any illegal products. All **mCig®** products must only be used in connection with dry herbs, concentrates, or e-juice legal under state or local law. Minimum age to purchase this device is 18 Years Old.

LIMITED WARRANTY TERMS AND CONDITIONS

Keep out of reach of children and pets. Women pregnant should consult a physician before using the **mCig®** 3. Anyone with a life threatening illness should consult a physician before using our device. Never use the **mCig®** while operating a motor-vehicle, motor-craft, or heavy machinery. Use of the **mCig®** can increase the effects of alcohol consumption.

mCig.org